

Proximity Card Reader

125 kHz

Mircom™ Data Reader
Quick Start Guide

1.0 Introduction

A proximity card reader, based on RFID technology, is a key component of a physical security electronic access control system. While in operation it is capable of reading data stored on a proximity credential via radio frequency and without physical contact, and then passing the data obtained to the physical access control system. Access control systems typically manage and record the movement of individuals through a protected area, such as a locked door.

This Quick Start Guide is intended for experienced installing technicians. It is a basic reference to ensure all connections are properly made. For additional information please reference Mircom's website www.mircomgroup.com.

2.0 Reader Wiring

Wiegand		Magstripe	
Conductor	Function	Conductor	Function
Red	DC (5-16 VDC)	Red	DC (5-16 VDC)
Black	Ground	Black	Ground
Green	Data 0	Green	Data
White	Data 1	White	Clock
Brown	Red LED ^a	Brown	Red LED
Orange	Green LED ^b	Orange	Green LED
Yellow	Card Present	Yellow	Card Present
Blue	Beeper	Blue	Beeper
Violet		Violet	
Drain	Shield Ground	Drain	Shield Ground

NOTES:

^a**Single Line LED:** This is the standard operating mode and does not make use of the Orange conductor. The LED is Red when the reader is idle and flashes when a card is presented. The LED turns Green when the Brown Conductor is pulled low by the access control panel.

^b**Dual Line LED:** This mode makes use of both the Brown and Orange conductors. The Brown conductor controls the Red LED and the Orange conductor controls the Green LED. LED states are determined by the access control system option and capability.

3.0 Cable Requirements

24 AWG minimum, multi-conductor stranded with an overall foil shield, for example Belden 9535 or similar. Per the SIA's Wiegand specification, maximum cable length is 500-feet (152 m).

4.0 Output Formats

Wiegand (industry standard 26-bit Wiegand and custom Wiegand formats)
Magnetic Stripe (ABA Track II, clock and data, with card present)

5.0 Grounding

Shield (drain) continuity must run from the reader to the access panel. Shield (drain) and reader ground must be tied together at the access panel and connect to an earth ground at one point.

6.0 Power

Reader may be powered by the access panel. A linear power supply is recommended for best operation.

7.0 Voltage

5 to 16 VDC. 12 VDC at the reader is recommended for best operation.

Proximity Card Reader

125 kHz

Mircom™ Data Reader
Quick Start Guide

8.0 Troubleshooting

1. When the reader is first powered on it will beep 4-times and the LED will shine red.
2. Presenting a supported access credential will result in the reader beeping and the LED flashing once.

NOTE: The access panel controls LED functionality, such as switching the LED to green.

If the reader does not recognize the card or tag (no beep, no LED flash) or exhibits short read range, please see the table below for possible causes and solutions.

Possible Cause	Corrective Action
Incorrect cabling	Verify gauge, connections and cabling length
Not enough power	12 VDC recommended, 5 VDC at reader is minimum
Incorrect card used	Verify if card technology is supported
Reader/access panel not properly grounded	Earth ground needed - verify shield and reader ground are tied at access panel and connect to ground at one point
Supply generating interference	Linear power supply recommended, verify switching power supply before use

Should any of the corrective actions mentioned above does not improve performance, disconnect the reader from the access panel and power it with a separate power supply or 9VDC battery and re-test card functionality. By powering the readers separately, most variables that may lead to reduced performance can be eliminated. Should the problem persist, please contact Mircom directly.

FCC compliance Statement: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Product can be used without license conditions or restrictions in all European Union countries, including Austria, Belgium, Denmark, Finland, France, Germany, Greece, Ireland, Luxembourg, The Netherlands, Portugal, Spain, Sweden, and the United Kingdom, as well as other non-EU countries, including Iceland, Norway, and Switzerland.

Many Readers carry the following certifications:



Mircom reserves the right to make changes at any time without notice in prices, colours, materials, components, equipment, specifications and models and also to discontinue models.

© All other trademarks are the property of their respective owners.

25 Interchange Way
Vaughan (Toronto), Ontario Canada
L4K 5W3
Tel: +1-888-660-4655 Fax: +1-905-660-4113
Web: www.mircom.com



P/N: 01149-001 Rev. 2